X4-TECH

GB

BoomStar BT

USER MANUAL

Art.-Nr. 701322

CE

Inhalt | Content

Information on this user manual 14
Designated use 14
General notes 14
Importer and Service 15
Safety Guide 16
Additional guidelines for Bluetooth devices 17
Packing contents 17
Specifications 18
Getting started 19
Placing the speaker | Charging the battery 20
Making a connection 20
Accepting a phone call 21
Connecting external devices via cable 22
Interference from other devices 22
Cleaning and maintenance 22
Trouble shooting 23
Disposal 24

We are pleased that you have decided to buy our product and wish you an enjoyable and successful use.

Information on this user manual

This user manual contains important information for the safe use of the product. Therefore, for your own safety and for a successful use, please read this user manual completely before assembling and using the product.

Designated use

The BoomStar BT is an active Bluetooth loudspeaker system for listening to music. The integrated amplifier is powered by an internal rechargeable battery. The designated use is defined by the instruction manual and in following the appliance and the warnings mentioned in this user manual.

General notes

All mentioned company and product names are registered trademarks under the rights of their owners. All rights reserved.

No liabilities will be taken for damages or claims resulting out of not reading and/or not following the user guide and/or any form of modification on or in the product. Under these circumstances, no warranty services will be given.
Liability cannot be taken for consequential damages.

The contents of this user manual may differ from the product. If so, please consult additional manuals in the packing. Keep this user manual in a safe place. If you give this product away to a third party, make sure that you also pass on the user manual.

The CE conformity has been declared and proven, and the corresponding documents have been deposited with the manufacturer. For the reason of safety and CE-licensing it is not allowed to modify this unit in any way and/or use it for functions, other than the designated use.

Importer and Service

Service Address	**lived non food GmbH** TOR 8 – 9 Donaustraße 20 D-38120 Braunschweig
Phone	+49 (0) 531/224356-82
E-Mail	service@x4-tech.de
Internet	www.x4-tech.de

Adresse	**lived non food GmbH** Donaustraße 20 D-38120 Braunschweig
E-Mail	info@lived-non-food.de
Internet	www.lived-non-food.de

Safety Guide

Please read the safety guide before using the product. This information is for your safety and the protection of the device and devices connected. You will also find specific safety instructions in the following chapters of this user manual.

This product is not a toy and should not be handled by infants and small children. Children cannot assess the dangers connected with electrical devices.
Do not leave the packaging material lying around. Children might play with the plastic bags and risk suffocation.

This device should only be opened and/or repaired by an expert or a person who is qualified to do so. Only original spare parts may be used.

Keep this product away from water, dampness and high humidity. Keep this product away from vessels containing liquids, e.g., buckets, vases or plants.

The product may not be subjected to extreme heat or cold. Do not expose the product to intense sunlight, open fire or other heat sources: Storage temperature: -0°C to 60°C; Working temperature: 0°C to 40°C

Do not use this device in a tropical humid climate.
If the product is brought in from the cold to a warm area (e.g., during transport), condensation can occur within the unit. Let the device reach room temperature, before you use it.

This product has an integrated Lithium Ion battery. Please follow the following safety instructions: Batteries are not a toy and should not be handled by infants and small children.
Leaking or damaged batteries can cause burns or etchings on the skin.

Follow all safety instructions in this user's guide and the user guides of the connected devices.

If you have any doubts on the function or questions, please contact your local dealer or our service center.

Additional guidelines for Bluetooth devices

The short wave radio frequency signals of a Bluetooth device may impair the operation of other electronic and medical devices. Switch off the device where it is prohibited. Do not use the device in medical facilities, aircraft, automatic fire alarms or other automatically controlled devices. Keep this device at least 20 cm from pacemakers and other medical devices. Radio waves may impair the operation of pacemakers and other medical devices.

Packing contents

BoomStar Bass Station
USB charging cable
Line-In cable
User manual

Specifications

Bluetooth	4.0
Frequency	2.4 – 2.48 GHz
Connection mode	NFC
Range	5 – 10 m (depending on the connected device)
BT-Profile	HS/HF, A2DP, AVRCP, OPP
Power output	3 W
Speaker	40 mm
Frequency Response	100 Hz – 18 kHz
S/N Ratio	≥ 85 dB
THD	≤ 10 %
Impedance	4 Ω
Power supply	5 V mini USB
Li-ion battery	3.7 V | 850 mAh
Size	Ø 65 x 80 mm
Weight	328 g

Getting started

1. Power ON/OFF
2. USB and AUX interface
3. Recharge Indicator
4. Volume +
5. Preview/ Fast reverse
6. Next/Fast forward



7. Play/Pause/Answer/
   Hang up/
   Radial the phone
   Change Mode among
   Bluetooth/AUX via
   pressing it for 2 seconds
8. Volume -

The buttons may hold more than one function, depending on the selected mode and how long they are held.
The Li-Ion battery is inside the device and cannot be accessed from the outside without tools.

Placing the speaker

The BoomStar BT needs a plain and hard surface as a resonating body. A desk or a shelf is the best choice.

Charging the battery

Please fully charge the device before use. For charging, use the supplied USB cable. Insert the Mini-USB plug into the device and the other end into your computer or a USB charger with 5 V output. Charge the device at the first time for at least 5 hours. The green LED in the recharge indicator (3) will show on the device is fully charged.

Advice on the lifetime of batteries
It is advisable to let the battery go fully flat from time to time and then recharge it again fully for several hours. This refreshes the battery.

Making a connection

The BoomStar BT can connect to another Bluetooth device with Bluetooth or with NFC standard and is used as an external loudspeaker. If connected through Bluetooth, the song selection and other functions can be controlled through the BoomStar BT. When using a mobile phone, the BoomStar BT can receive calls and be used as a hands-free device.

Connecting through Bluetooth:
→ Switch the BoomStar BT on (1).
→ The device will make a sound and the blue Bluetooth symbol (7) will blink.
→ Switch on your Bluetooth device which you want to connect to and activate the Bluetooth function.
→ Your Bluetooth device will now show you other Bluetooth

devices nearby.
→ Select the device BOOMSTAR BT and press “connect”. If a password is required, please use “0000”.
→ The blue Bluetooth symbol (7) will stop blinking and switch on constantly when connected.
→ Start playing the music. You’re connected Bluetooth device will mute and the music will be played by the BoomStar BT.
→ Press the next/last button (5/6) to go to the last/next song.
→ Press the Bluetooth symbol (7) to pause the current song.

Note
The connection only needs to be programmed once. If you’re Bluetooth device has Bluetooth activated, the BoomStar BT will automatically connect any time the devices are near enough to each other.

Connecting through NFC
→ The smartphone/tablet must be equipped with the NFC function
→ Switch the BoomStar BT on (1).
→ Activate the NFC function on your device and, if needed when using Android, download a pairing app. (e.g. Tap and Pair)
→ Hold your device within a few centimetres (2 – 4 cm) of the control panel of the BoomStar BT
→ The BoomStar BT will now play the music from the phone.

Accepting a phone call

When the BoomStar BT is connected to a mobile phone with NFC standard, calls can be taken and the BoomStar BT can be used as a hands-free device.

→ When receiving a call, tip onto the blue Bluetooth symbol (7).
→ The music will automatically mute and the call will be received.
→ You can now speak and hear hands-free.
→ To end the call, tip onto the Bluetooth symbol (7).
→ To reject a call, press and hold the Bluetooth symbol (7) for two seconds.
→ To hold a call, press and hold the Bluetooth symbol (7) for two seconds.

Connecting external devices via cable

The BoomStar BT can also be used as a wired active speaker system.

→ Connect the headphone output of your music source (mobile device) with the BoomStar BT by using the supplied connection cable.
→ Press and hold the blue Bluetooth symbol (7) for 2 seconds to change to AUX mode.
→ Start playing the music.
→ The volume can be controlled through the BoomStar BT. Other controls are not possible.
→ To change back to Bluetooth mode, press and hold the Bluetooth symbol (7) for two seconds.

Interference from other devices

Because Bluetooth devices and wireless LAN (IEEE802.11b/g) use the same frequency, microwave interference may occur and resulting in communication speed deterioration, noise, or invalid connection if the system is used near a wireless LAN device. In such a case, perform the following. Use the system at least 10 m away from the wireless LAN device. If the system is used within 10 m of a wireless LAN device, turn off the wireless LAN device.

Cleaning and maintenance

Always use a soft, dry and lint-free cloth to clean the unit's exterior. If the device is extremely dirty you can use a soft cloth, dampened with water or a mild cleaning solution to clean. Never use any abrasive or harsh cleaning agents (e.g. alcohol, petrol or thinners) as these could damage the controls, casing or any markings and labels found on the device.

Trouble shooting

The device will not switch on.

- Is the battery charged?
- Check your connection and charging cables.

The BoomStar BT is not recognised by my Bluetooth device.

- Make sure that you have the newest update on your Bluetooth device.

My devices are connected, but I cannot hear anything.

- Make sure that the volume on both devices is set to maximum.
- Make sure that a song is being played.

My device is not accepting commands from the BoomStar BT.

- Your Bluetooth device does not support NFC standard. Please contact your local dealer or the manufacturer for an update.

Disposal

Electrical- and electronic devices must never be disposed of in the regular household waste!

Consumers are legally obligated and responsible for the proper disposal of electronic and electrical devices by returning them to collecting sites designated for the recycling of electrical and electronic equipment waste. For more information concerning disposal sites, please contact your local authority or waste management company.

Do not throw batteries and rechargeable batteries into the household waste!

Customers are legally obliged to return used and rechargeable batteries, whether they contain harmful substances* or not, designated disposal sites or collecting sites in shops selling batteries. By doing so you are contributing to a better and cleaner environment.

* marking: Cd= Cadmium; Hg= Mercury; Pb= Lead

10.2013

X4-TECH